


Adjusting Time on the 7810iR and 7810iR-ent

Beginning in 2007, most of the United States begins Daylight Saving Time at 2:00 AM on the second Sunday in March and reverts to standard time on the first Sunday in November. In the U.S., each time zone switches at a different time.

In the United States and Canada, clocks change at 2:00 AM local time.

In spring, clocks spring forward from 1:59 AM to 3:00 AM.

In fall, clocks fall back from 1:59 AM to 1:00 AM.



Press the box containing the date and time on the bottom right of the screen.

This will open the "Set Date and Time" window.

Set Time & Date

Month: 10, Day: 16, Year: 2002

Hour: 11, Min: 54, Time Zone: -5

AM Adjust for DST

Synchronized with Network Clock

Ok Cancel

On March 09, 2008 at 1:59AM:

Adjust time zone, according to chart, by one digit using up arrow.

Press "OK"

On April 06, 2008 at 1:59AM

Adjust time zone, according to chart, by one digit using down arrow.
You should now show your correct time zone.

Press "OK"

Time Zones			
	Before 3/9	3/9 to 4/6	After 4/6
Eastern	-5	-4	-5
Central	-6	-5	-6
Mountain	-7	-6	-7
Pacific	-8	-7	-8
Alaska	-9	-8	-9
Hawaii	-10	-9	-10

If you have any difficulties, please call AlarmNet Technical Support at (800) 222-6525.